

Type H NEMA - 1A through 50A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

Type	Code (Removable Button Head)		Code (Solid Button Head)	
	Fuse Element		Fuse Element	
	Silver	Copper	Silver	Copper
1H	EF1HNNCIR	EF1HNNCIR	EF1HNNCIF	EF1HNNCIF
2H	EF2HNNCIR	EF2HNNCIR	EF2HNNCIF	EF2HNNCIF
3H	EF3HNNCIR	EF3HNNCIR	EF3HNNCIF	EF3HNNCIF
5H	EF5HNNCIR	EF5HNNCIR	EF5HNNCIF	EF5HNNCIF
8H	EF8HNPCIR	EF8HNPCIR	EF8HNPCIF	EF8HNCCIF
10H	EF10HNPCIR	EF10HNCCIR	EF10HNPCIF	EF10HNCCIF
15H	EF15HNPCIR	EF15HNCCIR	EF15HNPCIF	EF15HNCCIF
20H	EF20HNPCIR	EF20HNCCIR	EF20HNPCIF	EF20HNCCIF
25H	EF25HNPCIR	EF25HNCCIR	EF25HNPCIF	EF25HNCCIF
30H	EF30HNPCIR	EF30HNCCIR	EF30HNPCIF	EF30HNCCIF
40H	EF40HNPCIR	EF40HNCCIR	EF40HNPCIF	EF40HNCCIF
45H	EF45HNPCIR	EF45HNCCIR	EF45HNPCIF	EF45HNCCIF
50H	EF50HNPCIR	EF50HNCCIR	EF50HNPCIF	EF50HNCCIF

Individual Box - Add /BOX at the end of the code

Type H NEMA - 60A through 100A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

Type	Code (Removable Button Head)		Code (Solid Button Head)	
	Fuse Element		Fuse Element	
	Silver	Copper	Silver	Copper
60H	EF60HNPCIR	EF60HNCCIR	EF60HNPCIF	EF60HNCCIF
75H	EF75HNPCIR	EF75HNCCIR	EF75HNPCIF	EF75HNCCIF
85H	EF85HNPCIR	EF85HNCCIR	EF85HNPCIF	EF85HNCCIF
95H	EF95HNPCIR	EF95HNCCIR	EF95HNPCIF	EF95HNCCIF
100H	EF100HNPCIR	EF100HNCCIR	EF100HNPCIF	EF100HNCCIF

Individual Box - Add /BOX at the end of the code