

Type IS - 1A through 50A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

Type	Code (Removable Button Head)	Code (Solid Button Head)
	Fuse Element	Fuse Element
	Silver	Silver
1IS	EF1ISPCIR	EF1ISPCIF
2IS	EF2ISPCIR	EF2ISPCIF
3IS	EF3ISPCIR	EF3ISPCIF
5IS	EF5ISPCIR	EF5ISPCIF
7IS	EF7ISPCIR	EF7ISPCIF
10IS	EF10ISPCIR	EF10ISPCIF
15IS	EF15ISPCIR	EF15ISPCIF
20IS	EF20ISPCIR	EF20ISPCIF
25IS	EF25ISPCIR	EF25ISPCIF
30IS	EF30ISPCIR	EF30ISPCIF
40IS	EF40ISPCIR	EF40ISPCIF
50IS	EF50ISPCIR	EF50ISPCIF

Individual Box - Add /BOX at the end of the code

Type IS - 65A through 100A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

Type	Code (Removable Button Head)	Code (Solid Button Head)
	Fuse Element	Fuse Element
	Silver	Silver
65IS	EF65ISPCIR	EF65ISPCIF
80IS	EF80ISPCIR	EF80ISPCIF
100IS	EF100ISPCIR	EF100ISPCIF

Individual Box - Add /BOX at the end of the code

Type IS - 125A through 200A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

Type	Code (Removable Button Head)	Code (Solid Button Head)
	Fuse Element	Fuse Element
	Silver	Silver
125IS	EF125ISPR	EF125ISPF
150IS	EF150ISPR	EF150ISPF
200IS	EF200ISPR	EF200ISPF

Individual Box - Add /BOX at the end of the code