

Type K - 1A through 50A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

| Type | Code (Removable Button Head) | | Code (Solid Button Head) | |
|------|------------------------------|-----------|--------------------------|-----------|
| | Fuse Element | | Fuse Element | |
| | Silver | Copper | Silver | Copper |
| 1K | EF1KNCIR | EF1KNCIR | EF1KNCIF | EF1KNCIF |
| 2K | EF2KNCIR | EF2KNCIR | EF2KNCIF | EF2KNCIF |
| 3K | EF3KNCIR | EF3KNCIR | EF3KNCIF | EF3KNCIF |
| 5K | EF5KPCIR | EF5KCCIR | EF5KPCIF | EF5KCCIF |
| 6K | EF6KPCIR | EF6KCCIR | EF6KPCIF | EF6KCCIF |
| 8K | EF8KPCIR | EF8KCCIR | EF8KPCIF | EF8KCCIF |
| 10K | EF10KPCIR | EF10KCCIR | EF10KPCIF | EF10KCCIF |
| 12K | EF12KPCIR | EF12KCCIR | EF12KPCIF | EF12KCCIF |
| 15K | EF15KPCIR | EF15KCCIR | EF15KPCIF | EF15KCCIF |
| 20K | EF20KPCIR | EF20KCCIR | EF20KPCIF | EF20KCCIF |
| 25K | EF25KPCIR | EF25KCCIR | EF25KPCIF | EF25KCCIF |
| 30K | EF30KPCIR | EF30KCCIR | EF30KPCIF | EF30KCCIF |
| 40K | EF40KPCIR | EF40KCCIR | EF40KPCIF | EF40KCCIF |
| 50K | EF50KPCIR | EF50KCCIR | EF50KPCIF | EF50KCCIF |

Individual Box - Add /BOX at the end of the code

Type K - 65A through 100A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

| Type | Code (Removable Button Head) | | Code (Solid Button Head) | |
|------|------------------------------|------------|--------------------------|------------|
| | Fuse Element | | Fuse Element | |
| | Silver | Copper | Silver | Copper |
| 65K | EF65KPCIR | EF65KCCIR | EF65KPCIF | EF65KCCIF |
| 80K | EF80KPCIR | EF80KCCIR | EF80KPCIF | EF80KCCIF |
| 100K | EF100KPCIR | EF100KCCIR | EF100KPCIF | EF100KCCIF |

Individual Box - Add /BOX at the end of the code

Type K - 140A through 200A

11kV through 38kV



Illustrative

- Interrupting Capacity Assured.
- Contact us about other standards, currents and curves.

| Type | Code (Removable Button Head) | | Code (Solid Button Head) | |
|------|------------------------------|----------|--------------------------|----------|
| | Fuse Element | | Fuse Element | |
| | Silver | Copper | Silver | Copper |
| 140K | EF140KPR | EF140KCR | EF140KPF | EF140KCF |
| 200K | EF200KPR | EF200KCR | EF200KPF | EF200KCF |

Individual Box - Add /BOX at the end of the code